# UB Grinding Wheels for centerless grinder



# **UB Centerless Grinding Wheels,**

made from PVA synthetic fibers developed by our spinning technology and bonded with thermosetting resins. Abrasive grains are tightly bound inside of PVA fibers. Its elasticity effect offers smooth and continuous grinding without scratches and heat generation.



### **Major Applications:**

cylindrical parts, such as rods or shafts for 4-wheel vehicles and front fork pipes for motorcycles



shock absorber



front fork pipes



car parts

### Wheel specifications & Dimension table

Abrasive		Grade	Physical Properties	
ND60	NS600			
ND90	NS700	S	90W-1.6	
ND120	NS800	M	130W-1.3	
ND220	NS1000	Н	150W-1.2	
	NS1500	-		

				Unit:mm
DT	150	205	255	305
405				
455				
510				
610				

For other dimensions, please contact us.

### Physical Properties Symbols

130 W - 1.3 ①Young's Modulus: A large figure indicates harder structure. Real Young's Modulus = ①×10MPa

②Measurement condition: "W" for wet condition.

3Strain(%): A large figure indicates higher elongation.

## Cautions for operation

- 1. Do not use beyond the maximum peripheral speed (m/s) indicated on each wheel or inspection card.
- 2. Check all wheels before installing, and do not use the wheel that has cracking, fractures or chipping.
- 3. When tightening down the flange bolts with a torque wrench, tightening torque is calculated as below:

MQ (tightening torque) =  $\frac{0.2 \times d \times p \times Af}{n}$  MQ: proper tightening torque (N·m)

d :bolt diameter (cm)

p : proper pressure of flange contact area (6-7 MPa)

Af : flange contact area (cm²)

n : number of bolts

- 4. Coolant: designed for wet grinding, water-soluble type is recommended.
- 5. Need 3 minutes idling before operation and 10 minutes de-watering after operation.
- 6. Addition to the above cautions, always handle, store, and use wheels in a careful manner according to A.N.S.I. Safety Code B7.1.

### Nippon Tokushu Kento Co., Ltd.

18 Oike-cho, Kisshoin, Minami-ku, Kyoto, 601-8327, JAPAN

Tel:+81-75-691-5141 Fax:+81-75-672-3590

Tokyo office 5-8-25 Yayoi-cho, Nakano-ku, Tokyo, 164-0013, JAPAN

Tel:+81-3-5342-3751 Fax:+81-3-5342-3753

https://www.nittokuken.co.jp/ E-mail Sales@nittokuken.co.jp

AG	Ε	N	T